

*Congratulations on your purchase of a fine, hand-built, Basslines bass guitar pickup! Installing this pickup in your bass isn't rocket science. And, if you're already handy with tools, it'll be a snap for you—and fun too! But if you have no experience handling red-hot soldering irons, you'd be well advised to take your new pickup and your trusty bass to a qualified guitar tech.*

## Wiring Diagram for Pickup Models:

**ASB-BO-4** Blackouts for Bass 4-string

**ASB-BO-5** Blackouts for Bass 5-string

### The basic steps for installation include:

1. Remove the strings from your guitar.
2. Remove the control plate.
3. De-solder the original pickup's wires from the controls, and make sure to remember where they were connected.
4. Remove the original pickup from the pickup cavity.
5. If your original pickups were passive (no wires connecting from the pickups to a battery), remove the original pots and output jack, and replace them with the provided 25k pots and stereo output jack. You will also use the provided .47mf capacitor for your tone pot.
6. Install the new 25k pots and stereo jack, and connect them as shown.
7. Tin the wires from your Basslines pickup, and solder them into place.
8. Connect the battery clip as shown in the diagram.
9. Connect the red wires from all pickups to the red wire from the battery clip.
10. Connect the black wire from the battery clip to the ring terminal of the output jack.
11. Replace the control plate, taking care to tuck in any loose wires.
12. Re-string your bass and adjust the pickup height so that your pickups are about 1/8" from the strings when they are pressed down at the highest fret on the neck. For basses with two pickups, adjust the bridge pickup's height first, and then set the height of the neck pickup so that the outputs of the two pickups balance properly.

5427 hollister avenue, santa barbara, ca 93111

tel 805.964.9610 fax 805.964.9749

www.seymourduncan.com

Fig. 1

