

*Congratulations on your purchase of a fine, hand-built, Basslines electric bass pickup! Installing this pickup in your bass isn't rocket science. And, if you're already handy with tools, it'll be a snap for you—and fun too! But if you have no experience handling red-hot soldering irons, you'd be well advised to take your new pickup and your trusty bass to a qualified tech.*

## Wiring Diagram for Pickup Models:

**STK-J1** Classic Stack®  
for Jazz Bass®

**STK-J2** Hot Stack®  
for Jazz Bass®

**SJB-5** Passive 5-string  
Stack®

### The basic steps for installation include:

1. Remove the strings from your bass.
2. Remove the control plate and flip it over.
3. De-solder the original pickup's wires from the controls and make sure to remember where they were connected.
4. Remove the pickup from the pickup cavity.
5. Put your Basslines pickup into the pickup cavity.
6. Tin the wires from the Basslines pickup, and then solder them into place.
7. Replace the control plate.
8. Re-string your bass, and adjust the pickups so they are set about 1/8" from the strings when they are pressed down at the highest fret on the neck.

5427 hollister avenue, santa barbara, ca 93111  
tel 805.964.9610 fax 805.964.9749  
www.basslines.com

This wiring is for both the  
Jazz Bass Classic Stack (STK-J1)  
and the  
Jazz Bass Hot Stack (STK-J2)

